ASSIGNMENT 3

Textbook Assignment: "Horizontal Construction." Pages 3-1 through 3-19.

Learning Objective: Identify and describe road nomenclature and associated terminology used in construction drawings.

- 3-1. Which of the following is NOT an example of a military road?
 - 1. Two-lane highway
 - 2. Airfield runway
 - 3. Parking apron
 - 4. Quarry hauling road
 - A. Cut
 - B. Final grade
 - C. Existing grade
 - D. Fill
 - E. Subgrade
 - F. Surface

Figure 3A

IN ANSWERING QUESTIONS 3-2 THROUGH 3-5, SELECT FROM FIGURE 3A THE TERM THAT IS BEST DEFINED BY THE QUESTION.

- 3-2. The completed road surface elevation.
 - 1. B
 - 2. C
 - 3. E
 - 4. F
- 3-3. The undisturbed earth on an initial survey.
 - 1. B
 - 2. C
 - 3. E
 - 4. F

- 3-4. The distance required to get down to the final grade.
 - 1. A
 - 2. в
 - 3. D
 - 4. F
- 3-5. The portion of the road that is at final grade.
 - 1. C
 - 2. D
 - 3. E
 - 4. F
- 3-6. What term best describes the difference in elevation between the edge of the finished road and the center line?
 - 1. Slope ratio
 - 2. Superelevation
 - 3. Crown
 - 4. Roadway
- 3-7. What term defines the limits of the earthwork for a road?
 - 1. Roadbed
 - 2. Shoulder
 - 3. Traveled way
 - 4. Roadway
- 3-8. You are the notetaker on a road survey crew. All man-made objects should be noted in the book in what manner?
 - 1. By station number only
 - By distance from the center line only
 - 3. By station number and distance from the center line
 - 4. By the approximate location and distance

- 3-9. The drawing that contains construction limits, station markings, and all curve information is known by what name?
 - 1. Profile plan
 - 2. Road plan
 - 3. Plan-and-profile sheet
 - 4. Site plan
- 3-10. What is the minimum information needed by a survey crew to perform the preliminary route survey?
 - 1. Selected route
 - 2. Aerial photographs
 - 3. Area topography
 - 4. Plan-and-profile sheet
- 3-11. Which of the following terms is another name for "I" when discussing curve data?
 - 1. Degree of curvature
 - 2. Deflection angle
 - 3. Radius
 - 4. Interior angle
- 3-12. Which of the following angles describe the relationship between the radius and (a) the point of curvature and (b) the point of tangency?
 - 1. (a) 45° angle (b) 90° angle
 - 2. (a) 90° angle (b) 45° angle
 - 3. (a) 45° angle (b) 45° angle
 - 4. (a) 90° angle (b) 90° angle
- 3-13. The length of a curve is measured from what points?
 - 1. From the PI to the PC and the $$\operatorname{\textsc{PT}}$$
 - Along the curve from the PC to the PT
 - 3. Along the radius to the PT
 - 4. Along the radius to the PC
- 3-14. What is the radius of a 30° curve?
 - 1. 198.90 ft
 - 2. 189.90 ft
 - 3. 190.98 ft
 - 4. 198.98 ft

- 3-15. If I = 62° and D = 30°, what is the length of the curve?
 - 1. 206.67 ft
 - 2. 206.76 ft
 - 3. 207.67 ft
 - 4. 207.76 ft
- 3-16. "Superelevation" is defined as the difference in elevation between the
 - 1. center line and the outside edge
 - 2. center line and the inside edge
 - 3. inside edge and the outside edge
 - 4. PC and the PT
- 3-17. A control point cannot be a PT or POT.
 - 1. True
 - 2. False
- 3-18. Vertical curves may have which of the following values?
 - 1. Positive only
 - 2. Negative only
 - 3. Positive or negative
- 3-19. A road profile is a vertical section along the center line.
 - 1. True
 - 2. False
- 3-20. A grade line may represent final elevation or subgrade elevation.
 - 1. True
 - 2. False
 - 3-21. A vertical curve differs from a horizontal curve in which, if any, of the following ways?
 - 1. The way the length is measured
 - 2. The stations start at 0 + 00
 - 3. Laid out using a constant radius
 - 4. None of the above

- a hill is what type of curve?
 - 1. Sag
 - 2. Undervertical
 - Overhead
 - 4. Summit
- When the center-line grade rises 3 feet in 75 feet horizontal distance, what is the slope of the grade line?
 - 1. +3.0%
 - 2. -3.0%
 - 3. +4.0%
 - 4. -4.0%
- In a road plan, what term is used 3-24. to designate grade points?
 - 1. Station
 - 2. Profile
 - 3. Elevation
 - 4. Grade
- On a road plan. station numbers 3-25. are (a) lettered and (b) located 3-30. in what manner?
 - 1. (a) Horizontally above the profile
 - (b) right of the appropriate vertical grid line
 - 2. (a) Horizontally below the profile
 - (b) left of the appropriate vertical grid line
 - 3. (a) Horizontally above the profile
 - (b) centered on the appropriate vertical grid line
 - 4. (a) Horizontally below the profile
 - (b) centered on the appropriate vertical grid line
- In a profile and grade-line 3-26. drawing, all drainage structures are dimensioned by
 - 1. station
 - 2. type
 - 3. detail
 - 4. notes

- 3-22. A vertical curve at the crest of 3-27. The minimum clearing width on the left side of the roadway is how much greater than construction limits?
 - 1. 5 ft
 - 2. 6 ft
 - 3. 10 ft
 - 4. 12 ft
 - 3-28. Which of the following materials may be used as a base course in road construction?
 - 1. Sand
 - 2. Gravel
 - 3. Concrete
 - 4. Each of the above
 - 3-29. The surface course is placed over the
 - 1. base
 - 2. subgrade
 - 3. subbase
 - 4. roadbed
 - A typical section of a road shows exactly what about the road?
 - 1. How it looks before construction begins
 - 2. How it will look upon completion
 - 3. How it should look after construction
 - 4. How it looks at station 0 + 00and the final station only
 - 3-31. A typical straight road section differs from a typical curve section in what way?
 - 1. Shape of the road only
 - 2. Width of the road only
 - Shape and width of the road 3.
 - You have completed a route survey 3-32. and are to draw cross sections from the notes. What type of section will be drawn first?
 - 1. Preliminary
 - 2. Final
 - 3. Typical
 - 4. As-built

- in conjunction with (a) what sections and (b) for which of the following purposes?
 - 1. (a) Final (b) to determine asbuilt conditions
 - 2. (a) As-built (b) to determine construction errors
 - 3. (a) Typical (b) to determine existing material usefulness
 - 4. (a) finished roadbed (b) to determine earthwork requirements
- Final cross sections show which of 3 - 34. the following information?
 - 1. Finished elevation
 - 2. Actual cross-sectional shape of 3-40. the curves
 - 3. Distances of ditches from the center line
 - 4. Each of the above
- When, if ever, should a route be 3-35. relocated due to drainage problems?
 - 1. When planned through a forest
 - 2. When located in a floodplain
 - 3. When underground springs are a mile away
 - 4. Never
- Which, if any, of the following actions should be taken during road construction to prevent standing puddles on the roadway?
 - 1. Slant the worked surface of the road to provide quicker runoff
 - 2. Cut ditches outside the construction limits
 - 3. Raise the final grade of the roadway
 - 4. None of the above
- A perforated pipe is placed in the 3-37. bottom of a trench and backfilled to a designated depth to lower the water table. What term describes this action?
 - 1. French drain
 - 2. Trenching
 - 3. Bleeders
 - 4. Tile drain

- 3-33. Preliminary cross sections are used 3-38. You lay out a 50-foot ditch for subsurface drainage. What is the minimum grade, in feet, allowed?
 - 1. 0.10
 - 2. 0.15
 - 3. 0.25
 - 4. 0.30
 - 3-39. Which, if any, of the following effects does rainfall have on a roadway?
 - 1. Cleans the road surface
 - 2. Erodes the roadway
 - 3. Weakens road if allowed to
 - 4. None of the above
 - Your center-line elevation is 0.25 feet higher than the edge of the road. What term best describes this condition?
 - 1. Superelevation
 - 2. Drainage
 - 3. Ditching
 - 4. Crown
 - 3-41. Which of the following factors should you consider when determining the size and type of roadway ditches?
 - 1. Soil types
 - 2. Lay of the land
 - 3. Volume of water
 - 4. Each of the above
 - Which of the following conditions 3-42. occur when using a minimum grade on ditches?
 - 1. Excessive erosion
 - 2. Increased water-runoff velocity
 - 3. Ponding effect
 - The purpose of check dams is to 3-43.
 - 1. collect water
 - 2. slow waters
 - 3. form ponds
 - 4. beautify the roaduay

- 3-44. What type of ditch should be used 3-50. The dimensions for the end zone are to move a large volume of water?
 - 1. V-bottom
 - 2. Diversion
 - 3. Trapezoidal
 - 4. Flat bottom
- 3-45. Which of the following materials has the greatest amount of runoff?
 - 1. Stones
 - 2. Solid rock
 - 3. Sand
 - 4 Silt
- 3-46. In road construction, whenever a road crosses a stream with a 9-foot cross drain, the drain structure used is called
 - 1. a culvert
 - 2. a bridge
 - 3. a diversion ditch
 - 4. a channel
- 3-47. Diversion ditches drain excess water away from the roadway to what system?
 - 1. Interceptor ditches
 - 2. Natural earth drains
 - 3. Culverts
 - 4. Storm drains

Learning Objective: Identify and describe airfield nomenclature as used in the construction of standard technical drawings.

- 3-48. What is another name for a runway?
 - 1. Landing strip
 - 2. Landing area
 - 3. Taxiway
 - 4. Transition surface
- What surface provides access to 3-49. and from the runway for aircraft?
 - 1. Apron
 - 2. Hardstand
 - 3. Taxiway
 - 4. End zone

- specified by what authority?
 - 1. Federal Aviation Authority
 - 2. Air wing commander
 - 3. Aircraft industry
 - 4. ABFC design criteria
- On airfields, flexible pavements 3-51. can be used in which of the following locations?
 - 1. Refueling sites
 - 2. Shoulders
 - 3. Service aprons
 - 4. Runways

Learning Objective: Identify and describe pavements and the basic standard materials used in the construction of roads and airfields.

- The terms "flexible pavement" and 3-52. "pavement" may be interchanged.
 - 1. True
 - 2. False
- 3-53. What asphaltic coat is used to help bind the base course to the surface course?
 - 1. Tack coat
 - 2. Seal coat
 - 3. Rain coat
 - 4. Prime coat
 - 3-54. Which of the following materials can be used as a subbase for roads and airfields?
 - 1. Portland cement
 - 2. Ashes
 - 3. Tar
 - 4. Each of the above
 - 3-55. Uncrushed, washed gravel should NOT be used as base course material due to which of the following factors?
 - 1. Too high a moisture content
 - 2. Lack of fine material
 - 3. Too much binder material
 - 4. Lack of clay content

- 3-56. When, if ever, should a base course 3-59. What is the most important of sandy and gravelly material be used?
 - For light loads with low-bearing values
 - 2. For limited use
 - 3. For heavy loads with high-bearing values
 - 4. Never
- A coarse, crushed aggregate is 3-57. placed in a relatively thin layer and rolled into place. This is the first step in preparing what type of base?
 - 1. Stabilized
 - 2. Coarse graded
 - 3. Waterbound
 - 4. Macadam
- When sand, gravel, and crushed rock 3-58. are not available, a base course can be developed from which of the following materials?
 - 1. Cinders
 - 2. Iron ore
 - 3. Shells
 - 4. Each of the above

- consideration when using caliche?
 - 1. Moisture content
 - 2. Gradation
 - 3. Compactive effort
 - 4. Drainage
- 3-60. What type of equipment is recommended for the compaction of tuff?
 - 1. Grader
 - 2. Scraper
 - 3. Sheepsfoot roller
 - 4. Smooth drum roller
- What is the maximum lift for a 3-61. bituminous base course, in inches?
 - 1. 1.5
 - 2. 2.5
 - 3. 3.5
 - 4. 4.5
- What thickness of bituminous base 3-62. course, in inches, is equal to 6 inches of concrete base course?
 - 1. 6
 - 2. 8
 - 3. 3
 - 4. 4